

## Installation Instructions

Ford Transit Custom (2018+)



Step

Instructions

1

Remove plastic covering on the backside of the display unit.



2

Remove 3 x screws, then unplug cables and set aside display unit.



- 3 Install internal bracket, fixing into place using 2 x hole locations as shown.



- 4 Return plugs to their original state, then place display unit into position.



- 5 Install side bracket behind the display unit using 1 x previously removed screw.



- 6 Using a sharp blade, carefully trim away 1 x indicated plastic locator from backside plastic covering.



- 7 Return 2 x screws and backside plastic covering to their original positions.



- 8 Install front dash bracket with 3 x screws provided.



Enjoy your new In Dash Mount!  
If you have any issues or questions, please contact us.

**Industrial Evolution.**