

Installation Instructions

Hyundai i40 (2011+)



Step

Instructions

1

Remove plastic trim



2

Unscrew 2 bolts



3

Remove & unplug A/C control unit



4

Install L+R side brackets behind stereo



5

Plug in & re-install A/C control unit & plastic trim piece from steps 1 - 3



6

Install front dash bracket with 4 black screws provided



If you have any questions or issues with installation, please contact us.
Industrial Evolution