

Industrial Evolution Pty Ltd Unit 27/159 Arthur Street Homebush West 2140 NSW TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766 www.industrialevolution.com.au

Installation Instructions

Toyota Camry (2021+)



Step

Instructions

1

Loosen indicated dash piece. Then remove 1 x cable.



2

Loosen and remove 2 x passenger dash pieces, then the control panel.



3

Insert 2 x provided clips for the bracket installation in Step 4.



PRODUCT DESIGN SOLUTIONS • EQUIPMENT & BRACKET DESIGN • ELECTRONIC PRODUCT DESIGN • PROTOTYPES • CAD DESIGN & ENGINEERING



Industrial Evolution Pty Ltd Unit 27/159 Arthur Street Homebush West 2140 NSW TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766 www.industrialevolution.com.au

4

Install first bracket using 2 x screws. Return control panel, then install left side bracket.



5

6

7

Loosen driver side panel and install right side bracket using 1 x existing screw.



Restore dash components and cables to their original state.



Enjoy your new InDash Mount!



If you have any issues or questions, please contact us. Industrial Evolution