

Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

Installation Instructions

Toyota Corolla (2019+)

2





Step Instructions

1 Remove plastic trimming from around the screen, then loosen and remove dash piece.







Remove and set aside air vent.





Remove 1 x screw from dash, then loosen right side of the dash as indicated.







Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

Install metal bracket as shown. Tuck under plastic surround and outside below surround. Press metal bracket hard into position. Drill 3 x holes locations using the bracket as a template.





5 Install small bracket in behind, fixing into place using 3 x supplied screws. Then, replace 1 x screw.







6 Return all dash pieces to their original state.









Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399

ABN 13 108 256 766 www.industrialevolution.com.au





7 Install front dash bracket using mounting positions underneath and on the left side.





8 Enjoy your new InDash Mount!





Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

If you have any issues or questions, please contact us.

Industrial Evolution