

Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399

ABN 13 108 256 766 www.industrialevolution.com.au

Installation Instructions

Toyota Fortuner (2016+)





Step Instructions

1 Remove left and right side pieces as well as the upper AC cover.







2 Using a sharp blade, carefully trim 1 x tab as shown on side piece. Repeat on other side piece.







Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

3 On the left side piece, remove 2 x indicated screws. Then, fix left side bracket in place.





4

Repeat for the right side piece.





5 Loosen front cover and AC control unit and carefully set aside. Remove 4 x screws as indicated.





6 Loosen display unit and carefully set it down. Remove 2 x indicated screws from each side.







Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

7 Slide bracket into place from the underside of the display unit and fix into place using 4 x screws.





8 Separate upper cover from the AC controls as shown. Then, place AC controls into the dash.





Set display unit back into dash. Replace 4 x screws and plastic cover piece.



9





Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

7 Place left and right side pieces back into position, followed by the upper AC cover.



Install front bracket using 4 x mounting locations.



Enjoy your new InDash Mount!

If you have any issues or questions, please contact us.

Industrial Evolution

8