

Industrial Evolution Pty Ltd Unit 27/159 Arthur Street Homebush West 2140 NSW TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766 www.industrialevolution.com.au

Installation Instructions

Toyota Land Cruiser 100 (1998-2007)



Instructions

Step 1

2

Carefully remove 2 x side vents, then remove 4 x indicated screws.



Loosen central unit and remove 4 x screws.



PRODUCT DESIGN SOLUTIONS • EQUIPMENT & BRACKET DESIGN • ELECTRONIC PRODUCT DESIGN • PROTOTYPES • CAD DESIGN & ENGINEERING



Industrial Evolution Pty Ltd Unit 27/159 Arthur Street Homebush West 2140 NSW TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766 www.industrialevolution.com.au

3 Place side bracket in place and mark the rib as shown. Use a sharp blade to trim as indicated.



4 Install bracket in place. Repeat process and install opposite side bracket. Reinstate dash pieces.



5

Install front bracket using 4 x mounting locations.



Enjoy your new InDash Mount! If you have any issues or questions, please contact us. Industrial Evolution