

Industrial Evolution Pty Ltd

Unit 27 / 159 Arthur Street Homebush West 2140 NSW

> Tel + 61 2 9763 5300 Fax + 61 2 9763 5399

> ABN: 13 108 256 766

www.industrialevolution.com.au

Toyota Prado 2007+ In-Dash Mount instructions



















Trim one piece of plastic sticking out on both sides. See photo. Remove 4 bolts







If you have any questions please call me. Brett: 043 0033 040

DISCLAIMER: Please note that this document is intended as a guide only. It is recommended that all installations be carried out by trained persons. Industrial Evolution accepts no responsibility for damages caused by the installation of these mounts by third party installers.