

## **Installation Instructions**

Volkswagen Transporter (2020+) In Dash Mount



Step

Instructions

1

Carefully loosen and remove 3 x dash pieces from passenger side.



2

Loosen dash piece, unplug cables and set aside.



PRODUCT DESIGN SOLUTIONS • EQUIPMENT & BRACKET DESIGN • ELECTRONIC PRODUCT DESIGN • PROTOTYPES • CAD DESIGN & ENGINEERING



3

Loosen speedometer surround. Then loosen and remove central plastic dash piece.



**4** Place first bracket in place as shown. Using the central hole as a guide, drill through the backing plastic.



5 Place second bracket behind and use provided screw to fix into place. Then use provided selftapper screw to secure second location.





6

Restore cables and dash pieces.



7

Place upper bracket in place as shown, then drill through plastic using the hole as shown.



8 Place small bracket in behind and fix into place using provided screw. Use provided self-tapper screw to secure second location.



PRODUCT DESIGN SOLUTIONS • EQUIPMENT & BRACKET DESIGN • ELECTRONIC PRODUCT DESIGN • PROTOTYPES • CAD DESIGN & ENGINEERING





Restore dash and speedometer components to their original state.



10

Install front bracket using 4x countersunk screws provided.



If you have any issues or questions, please contact us. Industrial Evolution

PRODUCT DESIGN SOLUTIONS • EQUIPMENT & BRACKET DESIGN • ELECTRONIC PRODUCT DESIGN • PROTOTYPES • CAD DESIGN & ENGINEERING